







NOTE: STANDOFF BRACKET LOCATIONS

ARE \pm 1".

DO NOT PREDRILL HOLES IN THE STRUCTURE. HOLES SHOULD BE MATCH DRILLED TO INSURE PROPER ALIGNMENT

3D MODEL AVAILABLE IN STEP FILE FORMAT ON OUR WEBSITE



